

# GDI Target Interface

Revised 09/01/2003



Metrowerks, the Metrowerks logo, and CodeWarrior are registered trademarks of Metrowerks Corp. in the US and/or other countries. All other tradenames and trademarks are the property of their respective owners.

Copyright © Metrowerks Corporation. 2003. ALL RIGHTS RESERVED.

**The reproduction and use of this document and related materials are governed by a license agreement media, it may be printed for non-commercial personal use only, in accordance with the license agreement related to the product associated with the documentation. Consult that license agreement before use or reproduction of any portion of this document. If you do not have a copy of the license agreement, contact your Metrowerks representative or call 800-377-5416 (if outside the US call +1-512-996-5300). Subject to the foregoing non-commercial personal use, no portion of this documentation may be reproduced or transmitted in any form or by any means, electronic or mechanical, without prior written permission from Metrowerks.**

Metrowerks reserves the right to make changes to any product described or referred to in this document without further notice. Metrowerks makes no warranty, representation or guarantee regarding the merchantability or fitness of its products for any particular purpose, nor does Metrowerks assume any liability arising out of the application or use of any product described herein and specifically disclaims any and all liability. **Metrowerks software is not authorized for and has not been designed, tested, manufactured, or intended for use in developing applications where the failure, malfunction, or any inaccuracy of the application carries a risk of death, serious bodily injury, or damage to tangible property, including, but not limited to, use in factory control systems, medical devices or facilities, nuclear facilities, aircraft navigation or communication, emergency systems, or other applications with a similar degree of potential hazard.**

USE OF ALL SOFTWARE, DOCUMENTATION AND RELATED MATERIALS ARE SUBJECT TO THE METROWERKS END USER LICENSE AGREEMENT FOR SUCH PRODUCT.

## How to Contact Metrowerks

|                        |  |
|------------------------|--|
| Corporate Headquarters | Metrowerks Corporation<br>7700 West Parmer Lane<br>Austin, TX 78729<br>U.S.A.                                      |
| World Wide Web         | <a href="http://www.metrowerks.com">http://www.metrowerks.com</a>  |
| Sales                  | Voice: 800-377-5416<br>Fax: 512-996-4910<br>E-mail: <a href="mailto:sales@metrowerks.com">sales@metrowerks.com</a> |
| Technical Support      | Voice: 800-377-5416<br>E-mail: <a href="mailto:support@metrowerks.com">support@metrowerks.com</a>                  |

# Table of Contents

---

|   |           |
|---|-----------|
| <b>1 Overview</b>   | <b>5</b>  |
| About this guide . . . . .  | 5         |
| Highlights . . . . .  | 6         |
| Requirements . . . . .  | 6         |
| <b>2 Getting Started with CodeWarrior and the HCS12 Serial Monitor, and more...</b>   | <b>7</b>  |
| Technical Considerations about GDI Target Interface . . . . .   | 7         |
| First Steps with CodeWarrior and the HCS12 Serial Monitor via GDI Target Interface using the Stationery Wizard . . . . .    | 8         |
| First Steps with CodeWarrior and setting HCS12 Serial Monitor via GDI Target Interface within an existing project . . . . . | 10        |
| <b>3 Getting Started with CodeWarrior and the SofTec InDART-HCS12, and more...</b>  | <b>13</b> |
| Technical Considerations about GDI Target Interface . . . . .   | 13        |
| First Steps with CodeWarrior and the SofTec inDART-HCS12 via GDI Target Interface using the Stationery Wizard . . . . .     | 14        |
| First Steps with CodeWarrior and setting SofTec inDART-HCS12 via GDI Target Interface within an existing project . . . . .  | 15        |
| <b>4 GDI Target Interface Manual</b>  | <b>19</b> |
| Introduction . . . . .  | 19        |
| Interfacing Your System with the Target . . . . .   | 20        |
| Hardware Connection . . . . .   | 20        |
| Loading the GDI Target Interface . . . . .  | 20        |
| GDI Target Interface Menu Entries . . . . .   | 22        |
| Load... . . . .   | 22        |
| Reset. . . . .  | 22        |
| Connect... . . . .  | 22        |
| Command Files . . . . .   | 22        |
| Set Hardware BP... . . . .  | 22        |
| Set Bank... . . . .   | 23        |

---

|   |               |
|---|---------------|
| GDI Target Interface Dialogs . . . . .                        | 23            |
| GDI Setup. . . . .  | 23            |
| Status Bar Information for the GDI Target Interface . . . . . | 25            |
| Status Messages . . . . .                                     | 25            |
| Stepping and Breakpoint Messages . . . . .                    | 26            |
| GDI Target Interface Default Environment . . . . .            | 27            |
| Default Target Setup. . . . .                                 | 27            |
| GDI Target Interface Environment Variables . . . . .          | 27            |
| GDI Target Interface Command Line commands. . . . .           | 29            |
| <br><b>5 Supported GDI DLLs</b>                               | <br><b>33</b> |
| HCS12 Serial Monitor . . . . .                                | 33            |
| Menu Entries . . . . .  | 33            |
| Monitor Communication... . . . .                              | 34            |
| Load Options.... . . . .                                      | 34            |
| Erase Flash . . . . .   | 34            |
| Trigger Module Settings . . . . .                             | 34            |
| Bus Trace . . . . .   | 34            |
| Monitor Setup Dialog . . . . .                                | 35            |
| SofTec inDART-HCS12 . . . . .                                 | 37            |
| Menu Entries . . . . .  | 37            |
| MCU Configuration . . . . .                                   | 38            |
| About . . . . .   | 38            |
| Trigger Module Settings . . . . .                             | 38            |
| Bus Trace . . . . .   | 38            |
| MCU Configuration dialog . . . . .                            | 39            |
| Communication Settings dialog . . . . .                       | 40            |
| About dialog. . . . .   | 42            |
| <br><b>6 HC12 and HCS12 Banked Memory support</b>             | <br><b>43</b> |
| Banked Memory Location Dialog Box. . . . .                    | 43            |
| PPAGE index tab . . . . .                                     | 44            |
| DPAGE index tab . . . . .                                     | 45            |

---

---

|   |           |
|---|-----------|
| EPAGE index tab . . . . .                               | 45        |
| Various index tab (not all Target Interfaces) . . . . . | 46        |
| Associated Commands . . . . .                           | 47        |
| Associated Environment Variables . . . . .              | 51        |
| <b>7 Target Interface Commands Files</b>                | <b>55</b> |
| Target Interface Associated Command Files . . . . .     | 55        |
| Startup Command File . . . . .                          | 56        |
| Reset Command File . . . . .                            | 56        |
| Preload Command File. . . . .                           | 56        |
| Postload Command File . . . . .                         | 57        |
| Vppon Command File . . . . .                            | 57        |
| Vppoff Command File . . . . .                           | 57        |
| Command Files dialog . . . . .                          | 58        |
| Associated Commands . . . . .                           | 59        |
| Associated Environment Variables . . . . .              | 61        |
| <b>8 On-Chip Hardware Breakpoint Module</b>             | <b>65</b> |
| Hardware Breakpoint Configuration dialog . . . . .      | 65        |
| Disabled mode . . . . .                                 | 67        |
| Automatic (controlled by debugger) mode . . . . .       | 67        |
| User Controlled mode . . . . .                          | 68        |
| Associated Commands . . . . .                           | 71        |
| Associated Environment Variables . . . . .              | 75        |
| <b>Index</b>  | <b>1</b>  |



# Overview

---

## About this guide

This document includes information to become familiar with the *GDI* Target Interface and to help you understand how to use this Target Interface. This document is divided into following sections:

- The [Introduction](#) section introduces the *GDI* Target Interface concept.
- The [Getting Started with CodeWarrior and the HCS12 Serial Monitor, and more...](#) section gives answers for common questions and describes how to use advanced features of the *HCS12 Serial Monitor* via *GDI* Target Interface.
- The [Getting Started with CodeWarrior and the SofTec InDART-HCS12, and more...](#) section gives answers for common questions and describes how to use advanced features of the *SofTec inDART-HCS12* via *GDI* Target Interface.
- The [Interfacing Your System with the Target](#) section contains information about the connection between the 3rd party debugging hardware and the debugger.
- The [GDI Target Interface Menu Entries](#) section gives a description of the *GDI* Target Interface specific menu entries.
- The [GDI Target Interface Dialogs](#) section gives a description of the *GDI* Target Interface specific dialog boxes.
- The [Status Bar Information for the GDI Target Interface](#) section describes the status bar messages for the *GDI* Target Interface.
- The [GDI Target Interface Default Environment](#) section lists all the variables used by this Target Interface to store the configuration.
- The [GDI Target Interface Command Line commands](#) section lists all the commands specific to this Target Interface.
- The [Supported GDI DLLs](#) section introduces current GDI DLLs, i.e. the [HCS12 Serial Monitor](#) and the [SofTec inDART-HCS12](#).
- The [HC12 and HCS12 Banked Memory support](#) section explains who to set/change code and data banks for HC12 and HCS12 derivatives.

- The [Target Interface Commands Files](#) section gives a description of the debugger command private files.
- The [On-Chip Hardware Breakpoint Module](#) section explains how to use the [Hardware Breakpoint Configuration dialog](#) to set hardware breakpoints and watchpoints.
- The [Index](#) contains all keywords of the *GDI* Target Interface.

## Highlights

- The *GDI* Target Interface allows you to debug with a 3rd party GDI DLL driver interface: The Metrowerks 8/16 bits debugger (and then the Metrowerks CodeWarrior IDE) might be connected to HC12 and HCS12 hardware using the Generic Debug Instrument Interface (Revision 1.2.6). A GDI DLL can be loaded via the GDI.TGT Target Interface. The GDI DLL must be compliant to the “*Metrowerks 8/16 bits debugger Connection to Debug Instrument Using GDI interface protocol*” specification. For more information on GDI DLL implementation and connection to the Metrowerks 8/16 bits debugger, please contact Metrowerks.
- 

## Requirements

In order to use the *GDI* Target Interface, please make sure that the 3rd Party GDI DLL driver has been installed. The *GDI* Target Interface can then be setup to open the 3rd Party GDI DLL. Note that this DLL can have a different name than GDI.DLL. For more information, please see section [Interfacing Your System with the Target](#).



# Getting Started with CodeWarrior and the HCS12 Serial Monitor, and more...

---

Thanks for choosing *CodeWarrior*. This section guides you through installation, licensing/registration and first steps with CodeWarrior and the *HCS12 Serial Monitor* via *GDI* Target Interface. It does not replace all the documentation provided, but gives you a good starting point.

## Technical Considerations about GDI Target Interface

The Metrowerks 8/16 bits debugger (and then the Metrowerks CodeWarrior IDE) might be connected to HCS12 hardware using the Generic Debug Instrument Interface (Revision 1.2.6). A GDI DLL can be loaded via the GDI.TGT Target Interface. The GDI DLL must be compliant to the “*Metrowerks 8/16 bits debugger Connection to Debug Instrument Using GDI interface protocol*” specification. For more information on GDI DLL implementation and connection to the Metrowerks 8/16 bits debugger, please contact Metrowerks.

The HCS12 Serial Monitor *hcs12serialmon.dll* is a GDI DLL compliant and loadable via the GDI Target Interface in CodeWarrior. This GDI DLL implements communication specifications described in the *HCS12 Serial Monitor* Application Note from Motorola, Inc.

When the debugger runs the *hcs12serialmon.dll* within the GDI Target Interface, it can communicate and debug hardware running the HCS12 Serial Monitor in full compliancy to the Motorola *HCS12 Serial Monitor* Application Note specifications.


Please refer to this Application Note for communication hardware requirements.

For more detail about the HCS12 Serial Monitor GDI dll, please see [HCS12 Serial Monitor](#) section.

## **First Steps with CodeWarrior and the HCS12 Serial Monitor via GDI Target Interface using the Stationery Wizard**


1. Run the *CodeWarrior IDE* with the shortcut created in the program group.
2. Choose the menu **File > New** to create a new project from a stationery.
3. Select *HC(S)12 New Project Wizard*, type in a project name and specify the project location. Press *OK*.
4. Please follow all wizard steps and make sure to select the **Motorola Serial Monitor Hardware Debugging** as connection.

**Figure 2.1 Wizard Connection Selection**



5. Choose the menu **Project > Debug** to start the debugger.
6. Now in the Monitor Setup dialog, choose the correct Host serial communication port if necessary. In the Load Options panel, you can specify not to program automatically your application (by default, mass erasing and flashing of target processor).

**Figure 2.2 Monitor Setup Dialog**




7. Press the OK button to start debugging.

## First Steps with CodeWarrior and setting HCS12 Serial Monitor via GDI Target Interface within an existing project


1. Run the *CodeWarrior IDE* with the shortcut created in the program group.
2. Open the project.
3. Choose the menu **Project > Debug** to start the debugger.
4. Choose in the debugger menu **Component > Set Target...** to select another target interface.

**Figure 2.3 GDI Target Interface Selection**



5. Now in the GDI Setup dialog, press the browse button and browse for the *hcs12serialmon* dll file.

**Figure 2.4 Browse for HCS12SerialMon GDI DLL**




6. Now in the Monitor Setup dialog, choose the correct Host serial communication port if necessary. In the *Load Options* panel, you can specify not to mass erase automatically the target processor before flashing (by default, mass erasing is performed).

**Figure 2.5 Monitor Setup Dialog**

## Getting Started with CodeWarrior and the HCS12 Serial Monitor, and more...

*First Steps with CodeWarrior and setting HCS12 Serial Monitor via GDI Target Interface within an existing*

---



7. Press the OK button to start debugging.

# Getting Started with CodeWarrior and the SofTec InDART-HCS12, and more...

---

Thanks for choosing *CodeWarrior*. This section guides you through installation, licensing/registration and first steps with CodeWarrior and the *SofTec inDART-HCS12* via *GDI* Target Interface. It does not replace all the documentation provided, but gives you a good starting point.

## Technical Considerations about GDI Target Interface

The Metrowerks 8/16 bits debugger (and then the Metrowerks CodeWarrior IDE) might be connected to HCS12 hardware using the Generic Debug Instrument Interface (Revision 1.2.6). A GDI DLL can be loaded via the GDI.TGT Target Interface. The GDI DLL must be compliant to the “*Metrowerks 8/16 bits debugger Connection to Debug Instrument Using GDI interface protocol*” specification. For more information on GDI DLL implementation and connection to the Metrowerks 8/16 bits debugger, please contact Metrowerks.

The *SofTec\_BDM12.dll* is a GDI DLL compliant and loadable via the GDI Target Interface in CodeWarrior. This GDI DLL is the driver for *SofTec inDART\_HCS12* in-circuit debugger/programmer unit.

When the debugger runs the *SofTec\_BDM12.dll* within the GDI Target Interface, it can communicate and debug hardware connected through the SofTec in-circuit debugger/programmer unit.

Please refer to “*inDART®-HCS12In-Circuit Debugger/Programmer for Motorola HCS12 Family FLASH Devices User’s Manual*” from SofTec for communication hardware requirements and SofTec product installation.


For more detail about the HCS12 Serial Monitor GDI dll, please see [SofTec inDART-HCS12](#) section.

## **First Steps with CodeWarrior and the SofTec inDART-HCS12 via GDI Target Interface using the Stationery Wizard**

1. Run the *CodeWarrior IDE* with the shortcut created in the program group.
2. Choose the menu **File > New** to create a new project from a stationery.
3. Select *HC(S)12 New Project Wizard*, type in a project name and specify the project location. Press *OK*.
4. Please follow all wizard steps and make sure to select the **inDART-HCS12 Hardware Debugging** as connection.



**Figure 3.1 Wizard Connection Selection**




5. Choose the menu **Project > Debug** to start the debugger.

## First Steps with CodeWarrior and setting SofTec inDART-HCS12 via GDI Target Interface within an existing project


1. Run the *CodeWarrior IDE* with the shortcut created in the program group.
2. Open the project.
3. Choose the menu **Project > Debug** to start the debugger.
4. Choose in the debugger menu **Component > Set Target...** to select another target interface.

**Figure 3.2 GDI Target Interface Selection**




5. Now in the GDI Setup dialog, press the browse button and browse for the **SofTec\_BDM12** dll file. Search for the **SofTec\_BDM12** dll where SofTec applications and drivers are installed.

**Figure 3.3 Browse for SofTec\_BDM12.dll GDI DLL**



6. When the **SofTec\_BDM12** dll is found, press OK. Please choose in the MCU Configuration dialog the correct target processor.

**Figure 3.4 MCU Configuration**



7. Press the OK button to start debugging.

## **Getting Started with CodeWarrior and the SofTec InDART-HCS12, and more...**

*First Steps with CodeWarrior and setting SofTec inDART-HCS12 via GDI Target Interface within an*

---

# GDI Target Interface Manual

---

## Introduction

An advanced feature of *Metrowerks debugger* for the embedded systems development world is the ability to load different Target Interfaces, which implements the interface with target systems. In this document, the specific features of the *GDI* Target Interface are described.

The Metrowerks 8/16 bits debugger (and then the Metrowerks CodeWarrior IDE) might be connected to HC12 and HCS12 hardware using the Generic Debug Instrument Interface (Revision 1.2.6). A GDI DLL can be loaded via the GDI.TGT Target Interface. The GDI DLL must be compliant to the “*Metrowerks 8/16 bits debugger Connection to Debug Instrument Using GDI interface protocol*” specification. For more information on GDI DLL implementation and connection to the Metrowerks 8/16 bits debugger, please contact Metrowerks.

With this interface, you can download an executable program from the *Metrowerks CodeWarrior HC12 Studio*, to an external target system based on a *Motorola HC12* or *HCS12*, which will execute the program. You will also have the feedback of the real target system behavior to *Metrowerks debugger*.

The debugger will fully supervise and monitor the MCU of the target system i.e. control the CPU execution. You can read and write in internal/external memory when the MCU is in Background Mode. You have full control over the CPU state with the possibility to stop execution, to proceed in single step mode and to set breakpoints in the code.

# Interfacing Your System with the Target

## Hardware Connection

The GDI Target Interface is by definition a Generic Debug Instrument interface. There is no specific hardware cable or else for this interface. Indeed, the debugging hardware is entirely bound to the GDI DLL loaded by the GDI target. Please refer to the GDI DLL designer/provider/3rd party to get details about hardware connections and setup.

## Loading the GDI Target Interface


Usually the target is set in the **[HI-WAVE]** section of the **PROJECT** file, through the statement **Target=GDI**.

In this way, the *GDI* Target Interface detects automatically that the target is connected to your system.

If no target is set in the **PROJECT** file or if a different target is set, you can load the *GDI* Target Interface.


Select in the main menu **Component > Set Target...**, as shown in *Figure 3.3*.

**Figure 4.1** Set Target dialog




The *Set Target* dialog is displayed. Choose *GDI Target Interface* in the list of proposed targets and click *OK*.

**Figure 4.2 List of available targets interfaces**



Once the GDI Target interface is loaded, the GDI Setup dialog is opened. A GDI DLL must be specified in the “Path and name of the GDI DLL” edit box. Pressing the Browse button opens a typical Windows file browser.

**Figure 4.3 GDI Setup dialog**




Once the GDI DLL is specified press OK, then follow specific setup requirements of the loaded GDI DLL.

# GDI Target Interface Menu Entries

After loading the *GDI* Target Interface, the *Target* menu item is replaced by *GDI*. The different entries of the *GDI* menu are described below:

Figure 4.4 GDI Menu entries.



## Load...

Choose **GDI > Load...** to load the application to debug, i.e. e.g. a **.abs** file. Note that this operation is only possible when a GDI DLL has been loaded. Also, in this case, the “GDI” menu entry gets the name of the GDI DLL loaded.

## Reset

The menu entry **GDI > Reset** executes the [Reset Command File](#) and resets the target system processor.

## Connect...

Select entry **GDI > Connect...** to display the [GDI Setup](#) dialog.

## Command Files

Select entry **GDI > Command Files** to display the *GDI* Target Interface [Command Files dialog](#).

## Set Hardware BP...

This is a generic menu entry is only displayed and only accessible after a GDI DLL has been successfully loaded. Also this menu entry is available only if the connection with the target system has been established.



Choose **GDI > Set Hardware BP...** to open the [Hardware Breakpoint Configuration dialog](#).

## Set Bank...

This is a generic menu entry is only displayed and only accessible after a GDI DLL has been successfully loaded. Also this menu entry is available only if the connection with the target system has been established.

Choose **GDI > Set Bank...** to open the [Banked Memory Location Dialog Box](#).

# GDI Target Interface Dialogs

This section describes the dialogs which are specific to the *GDI* Target Interface.


Those dialogs are:

- the [GDI Setup](#) dialog,
- the *GDI* Target Interface [Command Files dialog](#),
- the [Hardware Breakpoint Configuration dialog](#),
- the [Banked Memory Location Dialog Box](#),

## GDI Setup


Select entry **GDI > Connect...** to display the *GDI Setup* dialog.

**Figure 4.5 GDI Setup dialog.**



A GDI DLL must be specified in the “Path and name of the GDI DLL” edit box. Pressing the Browse button opens a typical Windows file browser.


**Figure 4.6 GDI DLL browser.**



# Status Bar Information for the GDI Target Interface

When a GDI DLL has been loaded, specific information belonging to the GDI dll are displayed in the debugger's status bar. If no GDI dll is loaded, "No link to Target" default message is displayed.

Figure 4.7 Status bar GDI default message



## Status Messages

### GDI ready

*Metrowerks debugger* is ready and waits until a new target or application is loaded. This message is generated once the *Metrowerks debugger* has been started and the connection to target system has been established.

### No Link To Target

No GDI dll is currently loaded or currently loaded GDI dll connection to the target system has failed.

### RUNNING

The application is currently executing on the target.

### HALTED

Execution of the application has been stopped on user request. The menu entry **Run > Halt** or the *Halt* icon in the tool bar has been selected.

### RESET

This message is generated when the *Metrowerks debugger* has been reset on user request. The menu entry **GDI > Reset** or the *Reset* icon in the tool bar has been selected, or the command Reset has been used.

## Stepping and Breakpoint Messages

### STEPPED

Execution of the application has been stopped after a single step on source level. The menu entry **Run> Single Step** or the *Single Step* icon in the tool bar has been selected.

### STEPPED OVER

Execution of the application has been stopped after a step over a function call. The menu entry **Run > Step Over** or the *Step Over* icon in the tool bar has been selected.

### STOPPED

Execution of the application has been stopped after a step out from function call. The menu entry **Run> Step Out** or the *Step Out* icon in the tool bar has been selected.

### TRACED

Execution of the application has been stopped after an single step on assembler level. The menu entry **Run > Assembly Step** or the *Assembly Step* icon in the tool bar has been selected.

### BREAKPOINT

Execution of the application has been stopped because a breakpoint has been reached.

### WATCHPOINT

Execution of the application has been stopped because a watchpoint has been reached.

---

# GDI Target Interface Default Environment

## Default Target Setup

As any other target, the *GDI* Target Interface can be loaded from the *Target* menu or can be set as a default target in the `PROJECT` file which should be located in the working directory .

Typically the target is set in the **[HI-WAVE]** section from the `PROJECT` file as shown above. However, if the target is not defined, yo can load the *GDI* Target Interface interactively. Please refer to section [Loading the GDI Target Interface](#) of this manual.

### Listing 4.1 Example of **[HI-WAVE]** section from `PROJECT` file:

---

```
[HI-WAVE]
Window0=Source      0    0  60  30
Window1=Assembly   60    0  40  30
Window2=Procedur   0   30  60  25
Window3=Register   60   30  40  30
Window4=Memory     60   60  40  40
Window5=Data       0   55  60  23
Window6=Data       0   78  60  22
Target=GDI
```

---

---

|             |  |
|-------------|--|
| <b>NOTE</b> | Please see the Manual Engine HC12.pdf for further information about the <code>PROJECT</code> file. |
|-------------|--|

---

## GDI Target Interface Environment Variables

This section describes the environment variables which are used by the *GDI* Target Interface.

The *GDI* Target Interface specific environment variables are:

- [COMSETTINGS](#)

Some other common GDI dlls features are using variables. Those variables are:

- [BNKA\\_MCUIDnnnn BANKWINDOWn](#)
- [CMDFILEn](#)
- [HWBPD\\_MCUIDnnn BKPT\\_REMAPn](#)

- [HWBPD MCUIDnnnn HBPMn](#)

These variables are stored in the **[GDI]** section from the PROJECT file.

---

**Listing 4.2 Example of [GDI] section from PROJECT file:**

---

```
[GDI]
COMSETTINGS=SETCOMM DRIVER NOPROTOCOL NOPERIODICAL "hcs12serialmon.dll"
```

---

---

## COMSETTINGS

### Short Description

Communication device settings

### Syntax

---

```
COMSETTINGS==SETCOMM DRIVER <PROTOCOL|NOPROTOCOL>
<PERIODICAL|NOPERIODICAL> "<GDI DLL file (and path)>"
```

---

### Alias

None

### File

PROJECT file

### Section

[GDI]

### Components

*GDI* Target Interface.

### Description

The communication port to be used on the host computer can be specified using the variable **COMSETTINGS**.

If **PROTOCOL** is specified, all the commands and responses sent and received are reported in the *Command Line* component of the debugger. If **NOPROTOCOL** is specified, no protocol is reported.

If **PERIODICAL** and **NOPERIODICAL** are not used in the GDI target interface.

All parameters are set according to the setup in the [GDI Setup](#) dialog.

For example,

```
COMSETTINGS=SETCOMM DRIVER NOPROTOCOL NOPERIODICAL  
"hcs12serialmon.dll"
```

## GDI Target Interface Command Line commands

This section describes the *GDI* Target Interface specific commands which can be used when the *GDI* Target Interface is set.

The *GDI* Target Interface specific commands are:

- [PROTOCOL](#)
- [RESET](#)

Some other common Target Interface features are using commands. Those commands are:

- [BANKWINDOW](#)
- [HWBPM](#)
- [CMDFILE](#)

Those commands can be entered in the file or in the *Command Line* component of the debugger.

---

### PROTOCOL

#### Short Description

switch on/off the *Show Protocol* functionality

#### Syntax

---

PROTOCOL ON|OFF

---

**Alias**

None

**Components**

*GDI* Target Interface.

**Description**

If this command is used, all the messages sent to and received from the *GDI* interface are reported in the *Command Line* window of the debugger.

For Example

PROTOCOL ON

---

**TIP**

---

The Show Protocol is a useful debugging feature if there is a communication problem.

---

---

**RESET****Short Description**

reset of the target board

**Syntax**

---

RESET

---

**Alias**

None

**Components**

*GDI* Target Interface.



### **Description**

With this command it is possible to reset the target from the *Command Line* component of the debugger.

For example,

RESET



# Supported GDI DLLs

## HCS12 Serial Monitor

The HCS12 Serial Monitor *hcs12serialmon.dll* is a GDI DLL compliant and loadable via the GDI Target Interface in CodeWarrior. This GDI DLL implements communication specifications described in the *HCS12 Serial Monitor Application Note* from Motorola, Inc.


When the debugger runs the *hcs12serialmon.dll* within the GDI Target Interface, it can communicate and debug hardware running the HCS12 Serial Monitor in full compliancy to the Motorola *HCS12 Serial Monitor Application Note* specifications.

Please refer to this Application Note for communication hardware requirements.

## Menu Entries

Once the *hcs12serialmon.dll* is loaded in the GDI target interface, the “GDI” menu entry is replaced by “MONITOR-HCS12”.

**Figure 5.1 Menu Entries**



Only specific HCS12 Serial Monitor entries are commented here. Regular menu entries are introduced in [GDI Target Interface Menu Entries](#). As shown above, menu

entries are not always identical. The left hand side menu is displayed when the target processor does not include the onchip DBG module and features. The right hand side menu is displayed when the target processor includes the onchip DBG module and features. Please refer to the “*Debugger HCS12 Onchip DBG Module User Interface*” manual to get find all related information.

## Monitor Communication...

Select entry **MONITOR-HCS12> Communications...** to display the [Monitor Setup Dialog](#) on *Monitor Communication* tab.

## Load Options...

Select entry **MONITOR-HCS12> Load Options...** to display the [Monitor Setup Dialog](#) on *Load Options* tab.

## Erase Flash

Select entry **MONITOR-HCS12> Erase Flash** to force immediate mass erase of the target processor flash.

## Trigger Module Settings

Select entry **MONITOR-HCS12> Trigger Module Settings...** to force immediate mass erase of the target processor flash. Please refer to the “*Debugger HCS12 Onchip DBG Module User Interface*” manual to get find all related information.


## Bus Trace

Select entry **MONITOR-HCS12> Bus Trace** to open the Trace window component. Please refer to the “*Debugger HCS12 Onchip DBG Module User Interface*” manual to get find all related information.

## Monitor Setup Dialog


The *Monitor Setup* dialog has two tabs, has shown below.

**Figure 5.2 Monitor Communication tab**



Within this tab, it is possible to set or modify the current serial communication port when opening the “*HOST Serial Communication Port*” drop down list. Checking “*Show Monitor TX/RX*” reports in the debugger Command Line window all low level communication frames between the host computer and the HCS12 Serial Monitor.

**Figure 5.3 Load Options tab**



Within this tab, unchecking “*Enable Automatic Erase Flash on Load*” avoids mass erasing the target processor before flashing the application, operation which is performed by default. It is therefore possible to flash several applications. However, it is the user responsibility to avoid flash/code overwriting.

# SofTec inDART-HCS12

The *SofTec\_BDM12.dll* is a GDI DLL compliant and loadable via the GDI Target Interface in CodeWarrior. This GDI DLL is the driver for *SofTec inDART\_HCS12* in-circuit debugger/programmer unit.


When the debugger runs the *SofTec\_BDM12.dll* within the GDI Target Interface, it can communicate and debug hardware connected through the SofTec in-circuit debugger/programmer unit.

Please refer to “*inDART®-HCS12 In-Circuit Debugger/Programmer for Motorola HC12 and HCS12 Family FLASH Devices User’s Manual*” from SofTec for communication hardware requirements and SofTec product installation.

## Menu Entries

Once the *SofTec\_BDM12.dll* is loaded in the GDI target interface, the “GDI” menu entry is replaced by “inDART-HCS12”.

**Figure 5.4 Menu Entries**



Only specific inDART-HCS12 entries are commented here. Regular menu entries are introduced in [GDI Target Interface Menu Entries](#). As shown above, menu entries are not always identical. The left hand side menu is displayed when the target processor does not include the onchip DBG module and features. The right hand side menu is displayed when the target processor includes the onchip DBG module and features. Please refer to the “*Debugger HCS12 Onchip DBG Module User Interface*” manual to get find all related information.

## MCU Configuration

Select entry **inDART-HCS12> MCU Configuration** to display the [MCU Configuration dialog](#).

## About

Select entry **inDART-HCS12> About...** to display the [About dialog](#).

## Trigger Module Settings

Select entry **inDART-HCS12> Trigger Module Settings...** to force immediate mass erase of the target processor flash. Please refer to the “*Debugger HCS12 Onchip DBG Module User Interface*” manual to get find all related information.

## Bus Trace

Select entry **inDART-HCS12> Bus Trace** to open the Trace window component. Please refer to the “*Debugger HCS12 Onchip DBG Module User Interface*” manual to get find all related information.




## MCU Configuration dialog

The Hardware Model drop down list can be expanded to select another type of BDM debug interface than the inDART-HCS12. Note that at this document release time, only the inDART-HCS12 is available.

The *Device Code* drop down list can be expanded to select another HCS12 derivative.

Pressing the *Communication Settings* button opens the [Communication Settings dialog](#).

**Figure 5.5** MCU Configuration dialog



## Communication Settings dialog

The *Bus Clock Selection* group is intended to setup the best BDM synchronization between the *inDART-HCS12* interface and the target processor. If the target hardware provides a BDM synchronization clock signal, the *inDART-HCS12* ECLK line should be used and connected to this line to get the most precise synchronization.


In other cases, the *Automatic Detection* option can be specified. The user can also specify manually a BDM frequency (usually (external oscillator frequency/2)). pressing the *Find* button makes the *inDART-HCS12* driver search and display the current BDM frequency.

Note that the manual frequency option is not compatible with application changing the target processor bus speed via the onchip PLL. Indeed, the BDM communication clock is derived from the device bus clock. Please use *Automatic Detection* or *ECLK signal* options for this purpose.

The *BDM Clock* group and radio button options are rather bound to derivatives having synchronization problems. Please check the target processor errata sheet if BDM communication problems occur when the application changes the target processor bus speed via the onchip PLL.

Please refer to “*inDART®-HCS12 In-Circuit Debugger/Programmer for Motorola HC12 and HCS12 Family FLASH Devices User’s Manual*” from SofTec for further details.


Figure 5.6 Communication Settings dialog



## About dialog

This dialog belongs to the SofTec GDI dll and provides information about the *SofTec\_BDM12.dll* release and version.

**Figure 5.7 About dialog**



# HC12 and HCS12 Banked Memory support

---

The PPAGE, DPAGE and the EPAGE banked memory location are supported by the *Metrowerks debugger* Target Interfaces, depending on the debugged application and on the debugged *HC12/HCS12* derivative.

## Banked Memory Location Dialog Box

The *Banked Memory Location* dialog box is available only if the connected derivative is a *Motorola HC12 (CPU12)* or *HCS12*.

The *Banked Memory Location* dialog box can be opened by selecting the menu entry "**TargetName**" > **Set Bank....** (In this section, **TargetName** is the name of the Target Interface, like *SDI*, *Hitex*, *BDIK*, *GDI*, *Noral-BDM*, etc.) Using some Target Interfaces, the *Banked Memory Location* dialog box automatically pops up when the Target Interface is used with a *Motorola HC12* or *HCS12* derivative that supports banking. In this case, it also pops up when the banked memory area locations are not defined in the project file of the current project directory.

In this dialog box you can define which banked memory you want to use and its location. The PPAGE, DPAGE and the EPAGE indexes are supported, if they are available on the currently connected *HC12* or *HCS12* derivative.


The *Banked Memory Location* dialog box can have up to four index tabs:

- The [PPAGE index tab](#),
- The [DPAGE index tab](#),
- The [EPAGE index tab](#),
- The [Various index tab \(not all Target Interfaces\)](#).

## PPAGE index tab

The PPAGE index tab of the *Banked Memory Location* dialog box lets you set up the PPAGE banked memory area.

**Figure 6.1 Banked Memory Location dialog (PPAGE index tab)**



Once you have enabled PPAGE memory banking by checking the *Enable Banked Memory Area* check box, you must set the start address and the end address of this memory range.

The PPAGE register address must be specified in hexadecimal (e.g. 0x35 for HC812A4, 0xFF for HC912DG128, 0x30 for MC9S12/HCS12 devices).

The first page number must be specified in hexadecimal. (e.g. 0x30 for devices with S12FTS256K flash, 0x38 for devices with S12FTS128K flash, 0x3C for devices with S12FTS64K flash, 0x0 for HC912DG128).

The number of pages must be specified in decimal (e.g. 0 to 256 for HC812A4, 8 for HC912DG128, 16 for devices with S12FTS256K flash, 8 for devices with S12FTS128K flash, 4 for devices with S12FTS64K flash).

---


|             |  |
|-------------|--|
| <b>NOTE</b> | For the <i>Hitex</i> Target Interface, the PPAGE index tab does not appear in this dialog box if the PPAGE register is not available on the currently connected <i>Motorola HC12</i> derivative. For this Target Interface it is not needed to enter the PPAGE register address. |
|-------------|--|

---

## DPAGE index tab

The DPAGE index tab of the *Banked Memory Location* dialog box lets you set up the DPAGE banked memory area.

**Figure 6.2 Banked Memory Location dialog (DPAGE index tab)**



Once you have enabled DPAGE memory banking by checking the *Enable Banked Memory Area* check box, you must set the start address and the end address of this memory range.

The first page number must be specified in hexadecimal (e.g. 0 for HC812A4).

The number of pages must be specified in decimal (e.g. 0 to 256 for HC812A4).

The DPAGE register address must be specified in hexadecimal (e.g. 0x34 for HC812A4).

---


|             |  |
|-------------|--|
| <b>NOTE</b> | For the <i>Hitex</i> Target Interface, the DPAGE index tab does not appear in this dialog box if the DPAGE register is not available on the currently connected <i>Motorola HC12</i> derivative. For this Target Interface it is not needed to enter the DPAGE register address. |
|-------------|--|

---

## EPAGE index tab

The EPAGE index tab of the *Banked Memory Location* dialog box lets you set up the EPAGE banked memory area.

**Figure 6.3 Banked Memory Location dialog (EPAGE index tab)**



Once you have enabled EPAGE memory banking by checking the Enable Banked Memory Area check box, you must set the start address and the end address of this memory range.

The first page number must be specified in hexadecimal (e.g. 0 for HC812A4).

The number of pages must be specified in decimal (e.g. 0 to 256 for HC812A4).

The EPAGE register address must be specified in hexadecimal (e.g. 0x36 for HC812A4).

---

|             |  |
|-------------|--|
| <b>NOTE</b> | For the <i>Hitex</i> Target Interface, the EPAGE index tab does not appear in this dialog box if the EPAGE register is not available on the currently connected <i>Motorola HC12</i> derivative. For this Target Interface it is not needed to enter the EPAGE register address. |
|-------------|--|


---

## Various index tab (not all Target Interfaces)

The Various index tab of the *Banked Memory Location* dialog box is not available for all Target Interfaces.



**Figure 6.4**



If you are using an *HC12* derivative which supports banking and you don't want to enable this mechanism, or if you want to use only one bank out of three, you can suppress the automatic display of the *Banked Memory Location* dialog by checking the *Display dialog at connection if banked memory locations not defined* check box.

---

|             |   |
|-------------|---|
| <b>NOTE</b> | The settings entered in this dialog box are stored for a later debugging session in the ["targetName"] section of the project file. |
|-------------|---|

---

---

|             |   |
|-------------|---|
| <b>NOTE</b> | When using the <i>Hitex</i> Target Interface and the M68HC12DG128 DProbeHC12-DG, at least one page must be defined from 0x8000 to 0xBFFF. Otherwise, some display problems might be encountered in the Memory component of the <i>Metrowerks debugger</i> . |
|-------------|---|

---

## Associated Commands

The following sections describe the Banked Memory Location Command Line commands which are used by the Target Interface. These variables are:

### [BANKWINDOW](#)

Those commands can be entered in the Target Interface associated command files or in the Command Line component of the debugger.

The Banked Memory Location commands which are used by the Target Interface are described as shown in the following table.

| Topic             | Description   |
|-------------------|---|
| Short Description | Provides a short description of the command.                      |
| Syntax            | Specifies the syntax of the command in a EBNF format.             |
| Description       | Provides a detailed description of the command and how to use it. |
| Example           | Small example of how to use the command.                          |

The following sections describe each command related to the Banked Memory Location available for the Target Interface. The variables are listed in alphabetical order.

---

## BANKWINDOW

### Short Description

Specify a banked memory area and its status (enable/disable).

### Syntax

---

```
BANKWINDOW [bank] [OFF|ON] [<range> <reg address> <num of pages> <first  
page>]  
with  
bank = PPAGE | DPAGE | EPAGE  
or  
BANKWINDOW VARIOUS [DLGATCONNECT|NODLGATCONNECT]
```

---

### Description

The command BANKWINDOW allows to set up the debugger to work in banked memory model.

Three different Banked Memory Area can be defined: DPAGE, EPAGE and PPAGE. Each banked memory area has an associated bank register, which is displayed in the *Register* component of the *Metrowerks debugger*.

Using BANWINDOW PPAGE... command will have the same effect than using the PPAGE index tab in the [Banked Memory Location Dialog Box](#).

Using BANWINDOW DPAGE... command will have the same effect than using the DPAGE index tab in the [Banked Memory Location Dialog Box](#).

Using BANWINDOW EPAGE... command will have the same effect than using the EPAGE index tab in the [Banked Memory Location Dialog Box](#).

Using BANWINDOW VARIOUS... command will have the same effect than using the Various index tab in the [Banked Memory Location Dialog Box](#).

A banked memory area is defined by its start address, end address and the address of the Bank register.

The first page number and number of pages parameters allows to see in the memory component only the available pages.

The status of the banking mechanism in the debugger is also monitored through this command: a command can be defined, but the debugger banking mechanism can be disabled.

Consider the command:

```
BANKWINDOW PPAGE ON 0x8000..0xBFFF 0x30 16 0x30
```

This command allows to use the banked memory model in the debugger using the MC9S12DP256B.

This commands means the PPAGE register located at address 0x30 must be used to build the PC address when the code is located in banked memory area, from 0x8000 to 0xBFFF. The 16 pages starting from page 0x30 in the memory map are visible (page 0x3F is the last one). Previous pages (0 to 0x2F) are not visible.

The PPAGE register (located at address 0x30) will be displayed in the register component.

The bank settings are stored in the ["targetName"] section of the PROJECT file using variable [BNKA\\_MCUIDnnnn\\_BANKWINDOWn](#).

### Example

The bank memory area status can be get typing BANKWINDOW without any parameters in the Command Line component.

```
in>bankwindow
PPAGE Settings:
Status: enabled
Reg. Adr: 0x30
Range: 0x8000 to 0xbfff
First Page: 0x30
Number of Pages: 16
```

```
DPAGE Settings:
Status: disabled
Reg. Adr: 0x34
Range: 0x7000 to 0x7fff
First Page: 0x0
Number of Pages: 256
```

```
EPAGE Settings:
Status: disabled
Reg. Adr: 0x36
Range: 0x400 to 0x7ff
First Page: 0x0
Number of Pages: 256
```

```
in>
```

The status of the PPAGE Banked Memory area can be changed:

```
in>BANKWINDOW PPAGE OFF
in>BANKWINDOW
PPAGE Settings:
Status: disabled
Reg. Adr: 0x30
Range: 0x8000 to 0xbfff
First Page: 0x30
Number of Pages: 16

DPAGE Settings:
Status: disabled
Reg. Adr: 0x34
Range: 0x7000 to 0x7fff
First Page: 0x0
Number of Pages: 256

EPAGE Settings:
Status: disabled
Reg. Adr: 0x36
Range: 0x400 to 0x7ff
First Page: 0x0
Number of Pages: 256
in>
```

## Associated Environment Variables

The following sections describe the Banked Memory Location environment variables which are used by the Target Interface. These variables are:

[BNKA MCUIDnnnn BANKWINDOWn](#)

These variables are stored in the ["targetName"] section from the project file.

Example of the [BDIK] target section from a project file:

---

[BDIK]

## HC12 and HCS12 Banked Memory support

### Associated Environment Variables

---

```
BNKA_MCUID03C6_BANKWINDOW0=BANKWINDOW PPAGE OFF 0x8000..0xBFFF 0x30 16 0x30
```

---

```
BNKA_MCUID03C6_BANKWINDOW1=BANKWINDOW DPAGE OFF 0x7000..0x7FFF 0x34 256 0x0
```

---

```
BNKA_MCUID03C6_BANKWINDOW2=BANKWINDOW EPAGE OFF 0x400..0x7FF 0x36 256 0x0
```

---

The Banked Memory Location environment variables which are used by the Target Interface are described as shown in the following table.

| Topic             | Description  |
|-------------------|--|
| Short Description | Provides a short description of the variable.                      |
| Syntax            | Specifies the syntax of the variable in a EBNF format.             |
| Default           | Shows the default setting for the variable.                        |
| Description       | Provides a detailed description of the variable and how to use it. |
| Example           | Small example of how to use the variable.                          |

The following sections describe each variable available for the Target Interface. The variables are listed in alphabetical order.

---

## BNKA\_MCUIDnnnn\_BANKWINDOWn

### Short Description

Contains a [BANKWINDOW](#) Command Line command to be used to set up the Banked Memory support.

### Syntax

---

```
BNKA_MCUIDnnnn_BANKWINDOWn=<one BANKWINDOW Command Line command>
```

---

with `nnnn` specifying the current processor target `mcuid`. Therefore, note that `BANKWINDOW` commands are clearly isolated for each current processor target/derivative `mcuid`, rather than being generic for the current target interface.

### Default

The banked memory area will be automatically setup by default, according to the selected processor target/derivative.

The default settings for the `VARIOUS` page is that the *Banked Memory Location* dialog is displayed automatically when connecting when settings are not done (do only apply to the *Hitex* Target Interface).

### Description

The [BNKA\\_MCUIDnnnn\\_BANKWINDOWn](#) variable specifies a command file definition using [BANKWINDOW](#) Command Line command. Three or four of those entries should be present in the `PROJECT` file, depending on the Target Interface.

Those variables are used to store the Banked Memory Location definition (range, address, number of pages) and status (enable/disable) specified either with the [BANKWINDOW](#) Command Line command or through the [Banked Memory Location Dialog Box](#).

### Example

```
BNKA_MCUID03C6_BANKWINDOW0=BANKWINDOW PPAGE OFF 0x8000..0xBFFF  
0x30 16 0x30  
BNKA_MCUID03C6_BANKWINDOW1=BANKWINDOW DPAGE OFF 0x7000..0x7FFF  
0x34 256 0x0  
BNKA_MCUID03C6_BANKWINDOW2=BANKWINDOW EPAGE OFF 0x400..0x7FF  
0x36 256 0x0  
BNKA_MCUID03C6_BANKWINDOW3=BANKWINDOW VARIOUS DLGATCONNECT
```





# Target Interface Commands Files

---

## Target Interface Associated Command Files

The Target Interfaces offer the possibility to play a specific command file on different events:

- at connection: [Startup Command File](#),
- at reset: [Reset Command File](#),
- right before a file is loaded: [Preload Command File](#),
- right after a file has been loaded: [Postload Command File](#).
- right before a “Non Volatile Memory” is erased or right before a file is programmed in “Non Volatile Memory”: [Vppon Command File](#). This command file can be used for example to enable a programming voltage by software. This command file is not available for all Target Interfaces.
- right after a “Non Volatile Memory” has been erased or right after a file has been programmed in “Non Volatile Memory”: [Vppoff Command File](#). This command file can be used for example to disable a programming voltage by software. This command file is not available for all Target Interfaces.

The command files full name and status (enable/disable) can be specified either with the [CMDFILE](#) Command Line command or using the [Command Files dialog](#).

You can use any *Metrowerks debugger* command in those files and take advantage of the wide set of commands introduced in the *Metrowerks debugger* manual to setup the target hardware on one of those events.

### Listing 7.1 Example of a command file content

---

```
WB 0x0035 0x00
```

---

WB 0x0012 0x11  
PROTOCOL OFF

---

The WB 0x0035 0x00 command sets memory location 0x35 to 0.

The WB 0x0012 0x11 command sets memory location 0x12 to 0x11.

The command PROTOCOL OFF switch of the Show Protocol.

## Startup Command File

The Startup command file is executed by the *Metrowerks debugger* straight after the Target Interface has been loaded.

The Startup command file full name and status (enable/disable) can be specified either with the [CMDFILE](#) STARTUP Command Line command or using the Startup index of the [Command Files dialog](#).

By default the STARTUP.CMD file located in the current project directory is enabled as the current Startup command file.

## Reset Command File

The Reset command file is executed by the *Metrowerks debugger* straight after the reset button, menu entry or Command Line command has been selected.

The Reset command file full name and status (enable/disable) can be specified either with the [CMDFILE](#) RESET Command Line command or using the Reset index of the [Command Files dialog](#).

By default the RESET.CMD file located in the current project directory is enabled as the current Reset command file.

## Preload Command File

The Preload command file is executed by the *Metrowerks debugger* right before an application is loaded to the target system through the Target Interface.

The Preload command file full name and status (enable/disable) can be specified either with the [CMDFILE](#) PRELOAD Command Line command or using the Preload index of the [Command Files dialog](#).

By default the PRELOAD.CMD file located in the current project directory is enabled as the current Preload command file.

## Postload Command File

The Postload command file is executed by the *Metrowerks debugger* right after an application has been loaded to the target system through the Target Interface.

The Postload command file full name and status (enable/disable) can be specified either with the [CMDFILE](#) POSTLOAD Command Line command or using the Postload index of the [Command Files dialog](#).

By default the POSTLOAD.CMD file located in the current project directory is enabled as the current Postload command file.

## Vppon Command File

The Vppon command file is executed by the *Metrowerks debugger* right before a “Non Volatile Memory” is erased or right before a file is programmed in “Non Volatile Memory” to the target system through the Target Interface Non Volatile Memory Control dialog (Flash... menu entry) or FLASH PROGRAM/ERASE commands from Flash Programming utilities.

The Vppon command file full name and status (enable/disable) can be specified either with the [CMDFILE](#) VPPON Command Line command or using the Vppon index of the [Command Files dialog](#).

By default the VPPON.CMD file located in the current project directory is enabled as the current Vppon command file.

This command file can be used for example to enable a programming voltage by software.

---

**WARNING!** This command file is not available for all Target Interfaces.

---

## Vppoff Command File

The Vppoff command file is executed by the *Metrowerks debugger* right after a “Non Volatile Memory” has been erased or right after a file has been programmed in “Non Volatile Memory” to the target system through the Target Interface Non Volatile Memory Control dialog (Flash... menu entry) or FLASH PROGRAM/ERASE commands from Flash Programming utilities.

The Vppoff command file full name and status (enable/disable) can be specified either with the [CMDFILE](#) VPPOFF Command Line command or using the Vppoff index of the [Command Files dialog](#).

By default the `VPPOFF.CMD` file located in the current project directory is enabled as the current Vppoff command file.

This command file can be used for example to disable a programming voltage by software.

---


**WARNING!** This command file is not available for all Target Interfaces.

---

## Command Files dialog

The Target Interface Command Files dialog can be opened selecting menu entry “**TargetName**” > **Command Files**. (In this section, **TargetName** is the name of the target, like *SDI*, *Hitex*, *BDIK*, *ICD-12*, *Noral-BDM*, etc.)

**Figure 7.1 Target Interface Command Files dialog**



Each index of this dialog corresponds to an event on which [Target Interface Commands Files](#) can be automatically run from the *Metrowerks debugger*: [Startup Command File](#), [Reset Command File](#), [Preload Command File](#), [Vppon Command File](#), (not available for all targets), [Vppoff Command File](#) (not available for all targets), or any other Target Interface specific command file.

The command file in the edit box is executed when the corresponding event occurred.

Using the *Browse* button, you can set up the path and name of the command file.

The *Enable Command File* check box allows to enable/disable a command file on a event. By default, all command files are enabled:

- the default Startup command file is STARTUP.CMD,
- the default Reset command file is RESET.CMD,
- the default Preload command file is PRELOAD.CMD,
- the default Postload command file is POSTLOAD.CMD.
- the default Vppon command file is VPPON.CMD.
- the default Vppoff command file is VPPOFF.CMD.

---

|             |  |
|-------------|--|
| <b>NOTE</b> | The settings performed in this dialog are stored for a later debugging session in the ["targetName"] section of the PROJECT file using variables CMDFILE0, CMDFILE1,... <a href="#">CMDFILEn</a> . |
|-------------|--|

---

## Associated Commands

This section describes the Command Files command which can be used when the Target Interface is set.

The Target Interface specific commands are:

### [CMDFILE](#)

Those commands can be entered in the command files or in the Command Line component of the *Metrowerks debugger*.

This section describes each command available for the Target Interface. The commands are listed in alphabetical order.

| Topic             | Description   |
|-------------------|---|
| Short Description | Provides a short description of the command.                      |
| Syntax            | Specifies the syntax of the command in a EBNF format.             |
| Description       | Provides a detailed description of the command and how to use it. |
| Example           | Small example of how to use the command.                          |

---

## **CMDFILE**

### **Short Description**

Defines a command file path, name and status (enable/disable).

### **Syntax**

---

```
CMDFILE <file kind> ON|OFF ["<file name and path>"]  
and  
file kind = STARTUP|RESET|PRELOAD|POSTLOAD|VPPON|VPPOFF
```

---

### **Description**

The CMDFILE command is to be used set up a command file full name and status (disabled/enabled).

This command allows to perform the same settings than using the [Command Files dialog](#) through the Command Line component.

The settings of a command file are stored in the ["targetName"] section of the PROJECT file using variable [CMDFILEn](#).

### **Example**

The list of available command files (and their status) can be get typing CMDFILE without any parameters in the Command Line component.

```
in>CMDFILE  
Hitex Target Interface Command Files:  
STARTUP ON startup.cmd  
RESET ON reset.cmd  
PRELOAD ON preload.cmd  
POSTLOAD ON postload.cmd
```

The status of the Startup command file can be changed:

```
in>CMDFILE STARTUP OFF "my own startup.cmd"
in>CMDFILE
Hitex Target Interface Command Files:
STARTUP OFF my own startup.cmd
RESET ON reset.cmd
PRELOAD ON preload.cmd
POSTLOAD ON postload.cmd
```

## Associated Environment Variables

This section describes the Command Files dialog environment variables which are used by the Target Interface.

### [CMDFILEn](#)

These variables are stored in the [ "targetName" ] section from the project file.

### Listing 7.2 Example of the [NORAL FLEX BDM] target section from the project file:

```
[NORAL FLEX BDM]
CMDFILE0=CMDFILE STARTUP ON "startup.cmd"
CMDFILE1=CMDFILE RESET ON "reset.cmd"
CMDFILE2=CMDFILE PRELOAD ON "preload.cmd"
CMDFILE3=CMDFILE POSTLOAD ON "postload.cmd"
CMDFILE4=CMDFILE VPPON ON "vppon.cmd"
CMDFILE5=CMDFILE VPPOFF ON "vploff.cmd"
```

The following section describes each variable available for the Target Interface. The variables are listed in alphabetical order.

| Topic             | Description  |
|-------------------|--|
| Short Description | Provides a short description of the variable.                      |
| Syntax            | Specifies the syntax of the variable in a EBNF format.             |
| Default           | Shows the default setting for the variable.                        |
| Description       | Provides a detailed description of the variable and how to use it. |
| Example           | Small example of how to use the variable.                          |

---

## **CMDFILEn**

### **Short Description**

Contains a CMDFILE Command Line command to be used to define a command file on a event.

### **Syntax**

---

CMDFILEn=<command file specified using CMDFILE Command Line command>

---

### **Default**

All command files are enabled by default.

The default Startup command file is STARTUP.CMD,

The default Reset command file is RESET.CMD,

The default Preload command file is PRELOAD.CMD,

The default Postload command file is POSTLOAD.CMD.

The default Vppon command file is VPPON.CMD.

The default Vppoff command file is VPPOFF.CMD.

### **Description**

The CMDFILEn variable specifies a command file definition using CMDFILE Command Line command. If there are four [Target Interface Commands Files](#) for the Target Interface, four of those entries should be present.

Those variables are used to store the command files status (enable/disable) and full name specified either with the [CMDFILE](#) Command Line command or using the [Command Files dialog](#).



**Example**

```
CMDFILE0=CMDFILE STARTUP ON "startup.cmd"  
CMDFILE1=CMDFILE RESET ON "reset.cmd"  
CMDFILE2=CMDFILE PRELOAD ON "preload.cmd"  
CMDFILE3=CMDFILE POSTLOAD ON "postload.cmd"  
CMDFILE4=CMDFILE VPPON OFF "vppon.cmd"  
CMDFILE5=CMDFILE VPPOFF OFF "vppoff.cmd"
```



# On-Chip Hardware Breakpoint Module

---

On some HC12 and HCS12 derivatives, an on-chip hardware breakpoint module can be used to set triggers. The *Metrowerks debugger* takes advantage of this embedded hardware breakpoint module to set hardware breakpoints and watchpoint.

To invoke this module, it is necessary to set up the debugger to use this on-chip hardware breakpoint module.

During the first connection, the hardware breakpoints module settings are resolved according to the specified derivative.


Afterwards, if the user change the derivative, it is the user responsibility to setup correctly the hardware breakpoints mechanism for the project.

This can be done using the [Hardware Breakpoint Configuration dialog](#).

## Hardware Breakpoint Configuration dialog

Choose “**TargetName**” > **Set Hardware BP...** menu command. The *Hardware Breakpoint Configuration* dialog, *Break Module Settings* index tab is displayed, as shown in Figure 7.1.


**Figure 8.1 Hardware Breakpoint Configuration dialog**



**Breakpoint Module Mode:** The *Mode* combo box allows to select between three different modes: *Disabled*, *Automatic (controlled by debugger)* and *User controlled* (See Figure 7.2).

This dialog allows to set up the hardware breakpoint module of the used *Motorola HC12* or *HCS12* derivative.

**Figure 8.2 Hardware Breakpoint Configuration Breakpoint Module mode**



## Disabled mode

When the hardware breakpoint module is disabled, it is not possible to set breakpoint in Flash or in EEPROM. It is also not possible to set any watchpoint, even if the application is loaded in RAM.

---

**NOTE** Some actions like “stepping over” or “stepping out” use one internal breakpoint and therefore can not be used when debugging in non volatile memory if the hardware breakpoint module is disabled.


---

## Automatic (controlled by debugger) mode

This is the default mode for the debugger.

If the *Automatic (controlled by debugger)* mode is selected, you have the possibility to set up to two breakpoints in *Non Volatile Memory* (or one watchpoint), as shown in Figure 7.3.

**Figure 8.3** Module base address edit box



**Breakpoint Module kind:** select here the hardware breakpoint module supported by the derivative currently connected: “use 16-Bits Break Module” for a *Motorola HC12* derivative and “use 22-Bits Break Module” for a *Motorola HCS12* derivative.

**Breakpoint Module base address (hex):** in order to set the debugger correctly, the address of the hardware breakpoint module must be set in the *Module base address* edit box. The Module base address is typically **0x20** for the *Motorola HC12* derivatives *M68HC912B32*, *M68HC912D60* and *M68HC912DG128*. The Module base address is typically **0x28** for the *Motorola HCS12* derivatives.

**Continue on illegal break:** this feature allows, when using the 16 Bits-break module to debug in banked memory model. The 16 bits break module does not allow to set a breakpoint in bank. To solve this problem, when the debugger stops on a hardware breakpoint, the address is compared to an internal breakpoint list. If the low 16 bits part of the address compare to the low 16 bits part of the address of a set breakpoint, the breakpoint is located in an alternate bank. The debugger then automatically restarts the target.

When those settings are done, any breakpoint which is set in *Non Volatile Memory* is considered by the debugger as an *Hardware Breakpoint*.

If your application is loaded in RAM, breakpoints are software breakpoints. In this case the *Hardware Breakpoint* module gives you the possibility to debug with breakpoints and watchpoint (only one watchpoint is available).

---

|             |   |
|-------------|---|
| <b>NOTE</b> | In Automatic mode, the <i>Motorola HC12</i> or <i>Motorola HCS12</i> hardware breakpoint modules allow only two breakpoints (or one watchpoint) at the same time. If you are debugging your code in FLASH, you can not set more than two breakpoints or one watchpoint.<br>Some actions like “stepping over” or “stepping out” use one internal breakpoint and therefore reduce your amount of hardware breakpoint to one. The M68HC812A4 does not have any Hardware Breakpoint module. |
|-------------|---|

---

## User Controlled mode


This mode allows you to fully set up the breakpoint module according to Motorola’s documentation.

According to the selected breakpoint module kind selected through the *Breakpoint Module Description* combo box in the Break Module Setup index tab, the *16-bits Break Module (User Mode)* or *22-bits Break Module (User Mode)* must be selected (the control are grayed in the *User Mode* index tab if the correct Mode (*User Controlled* and correct breakpoint module kind is not selected).

## 16-bits Break Module (User Mode)

The *16-bits Break Module (User Mode)* index tab allows to set up the hardware breakpoint module of the connected *Motorola HC12* derivative when the *Breakpoint Module mode* is set to “*User controlled*” and the *Breakpoint Module Kind* is set to use “*16-Bits Break Module*”.

Figure 8.4 16-bits Break Module (User Mode) index tab



The following registers can be modified:

- **BRKCT0**: Breakpoint Control Register 0
- **BRKCT1**: Breakpoint Control Register 1
- **BRKA**: Breakpoint Address Register
- **BRKD**: Breakpoint Data Register

For more information about those registers, please refers to your MCU reference manual section *Breakpoints* of the *Background Debug Mode (Development Support* part of the manual).

### CAUTION

When a hardware breakpoint or watchpoint is set in *User controlled* mode, the message displayed in the status bar when the breakpoint or watchpoint is reached is `ILLEGAL_BP`.  
If the control point set is a breakpoint, it is needed to perform a single


step before running again the target otherwise the target will endlessly break on the same address bus access.

---

## 22-bits Break Module (User Mode)

The *22-bits Break Module (User Mode)* index tab allows to set up the hardware breakpoint module of the connected *Motorola HCS12* derivative when the *Breakpoint Module mode* is set to “*User controlled*” and the *Breakpoint Module Kind* is set to use “*22-Bits Break Module*”.

**Figure 8.5 22-bits Break Module (User Mode) index tab**



The following registers can be modified:

- **BKPCT0**: Breakpoint Control Register 0
- **BKPCT1**: Breakpoint Control Register 1
- **BKP0**: Breakpoint Address Register
- **BKP1**: Breakpoint Data Register

For more information about those registers, please refers to your MCU reference manual section *Breakpoints* of the *Background Debug Mode (Development Support* part of the manual).



---

**CAUTION** When a hardware breakpoint or watchpoint is set in *User controlled* mode, the message displayed in the status bar when the breakpoint or watchpoint is reached is `ILLEGAL_BP`.  
If the control point set is a breakpoint, it is needed to perform a single step before running again the target otherwise the target will endlessly break on the same address bus access.

---

## Associated Commands

The following sections describe the Hardware Breakpoint Settings Command Line commands which are used by the Target Interface. These variables are:

### [HWBPM](#)

Those commands can be entered in the Target Interface associated command files or in the Command Line component of the debugger.

The Hardware Breakpoint Settings commands which are used by the Target Interface are described as shown in the following table.

| Topic             | Description   |
|-------------------|---|
| Short Description | Provides a short description of the command.                      |
| Syntax            | Specifies the syntax of the command in a EBNF format.             |
| Description       | Provides a detailed description of the command and how to use it. |
| Example           | Small example of how to use the command.                          |

The following sections describe each command related to the Banked Memory Location available for the Target Interface. The variables are listed in alphabetical order.

---

## HWBPM

### Short Description

Hardware Breakpoints module usage settings.

### Syntax

---

```
HWBPM
HWBPM MODE <MODE> BPM16BITS|BPM22BITS <module adr.> [SKIP_OFF|SKIP_ON]
with MODE = DISABLED|AUTOMATIC|USER

HWBPM SET16BITS <BRKCT0 value> <BRKCT1 value> <BRKA value> <BRKD value>
HWBPM SET22BITS <BKPCT0 value> <BKPCT1 value> <BKP0 value> <BKP1 value>
HWBPM REMAP_22BITS RANGE <start address> <end address> <mask>
HWBPM REMAP_22BITS DISPLAY
HWBPM REMAP_22BITS MCUID_DEFAULT
HWBPM REMAP_22BITS DELETE <range number>
```

---

### Description

The command `HWBPM` allows to set up the debugger to work with the on chip hardware breakpoints dialog.

Use `HWBPM` with no parameters to get the current breakpoints settings.

Using `HWBPM MODE...`, you can set up which module to use, the usage the debugger will do of the on-chip hardware breakpoint module, the on-chip module address, etc. This command will have the same effect than using the *Break Modules Settings* index tab in the [Hardware Breakpoint Configuration dialog](#).

Using `HWBPM SET16BITS...` command will have the same effect than using the *16-bits Break Module (User Mode)* index tab in the [Hardware Breakpoint Configuration dialog](#). Parameters set up through this command are only relevant when the *User controlled* mode is active and the 16 bits break module is used.

Using `HWBPM SET22BITS...` command will have the same effect than using the *22-bits Break Module (User Mode)* index tab in the [Hardware Breakpoint Configuration dialog](#). Parameters set up through this command are only relevant when the *User controlled* mode is active and the 22 bits break module is used.

---

|             |  |
|-------------|--|
| <b>NOTE</b> | The hardware breakpoints settings are stored in the ["targetName"] section of the PROJECT file using variable <a href="#"><u>HWBPD_MCUIDnnnn_HBPMn</u></a> . |
|-------------|--|

---

The HWBPM REMAP\_22BITS commands are used, for the 22-bits module, to perform remapping of pages, in order to be able to set breakpoints in non banked memory areas when using this on-chip break module. When selecting a derivative, this command is used by the debugger to set up the corresponding remapping needed for the specified derivative.

- HWBPM REMAP\_22BITS DISPLAY display all the currently set remapping, for the currently set derivative.
- HWBPM REMAP\_22BITS RANGE allows to specify that the prefix <mask> must be used to set a hardware breakpoint in range <start address> <end address>
- HWBPM REMAP\_22BITS MCUID\_DEFAULT allows to retrieve the derivative default setting (in case it has been modified using HWBPM REMAP\_22BITS RANGE... or HWBPM REMAP\_22BITS DELETE)
- HWBPM REMAP\_22BITS DELETE <range number> allows to delete a specific range. The range number is displayed when using HWBPM REMAP22BITS DISPLAY.

---

|             |   |
|-------------|---|
| <b>NOTE</b> | The range remapping are stored in the ["targetName"] section of the PROJECT file using variable <a href="#"><u>HWBPD_MCUIDnnn_BKPT_REMAPn</u></a> . |
|-------------|---|

---

### Example

The Hardware Breakpoints mechanism settings can be get typing HWBPM without any parameters in the Command Line component.

```
in>HWBPM
```

Hardware Breakpoints Module Settings:

Module kind: 22BITS

Module mode: Automatic

Module address: 0x28

Skip illegal BP (16bits only): off

HWBPM 16 bits: BRKCT0: 0x0 BRKCT1: 0x0 BRKA: 0x0 BRKD: 0x0

HWBPM 22 bits: BKPCT0: 0x0 BKPCT1: 0x0 BKP0: 0x0 BKP1: 0x0

The current Module mode can be modified to User controlled and the used on-chip hardware breakpoint module to the 16-bits one (relevant only if present on the hardware):

```
in>HWBPM MODE USER BPM16BITS 0x20 SKIP_OFF
```

```
in>HWBPM
```

Hardware Breakpoints Module Settings:

Module kind: 16BITS

Module mode: User Defined

Module address: 0x20

Skip illegal BP (16bits only): off

HWBPM 16 bits: BRKCT0: 0x0 BRKCT1: 0x0 BRKA: 0x0 BRKD: 0x0

HWBPM 22 bits: BKPCT0: 0x0 BKPCT1: 0x0 BKP0: 0x0 BKP1: 0x0

Enter values in the on-chip breakpoint module registers:

```
in>HWBPM SET16BITS 0xa4 0x0 0xc004 0x0
```

```
in>HWBPM
```

Hardware Breakpoints Module Settings:

Module kind: 16BITS

Module mode: User Defined

Module address: 0x20

Skip illegal BP (16bits only): off

HWBPM 16 bits: BRKCT0: 0xa4 BRKCT1: 0x0 BRKA: 0xc004 BRKD: 0x0

HWBPM 22 bits: BKPCT0: 0x0 BKPCT1: 0x0 BKP0: 0x0 BKP1: 0x0

Display the currently set remapping:

```
in>HWBPM REMAP_22BITS DISPLAY
HWBPM Remappings for 0x3CA:
Range0:    0x4000..0x7FFF mask: 0x3e
Range1:    0xC000..0xFFFF mask: 0x3f

Add a new remapping:
in>HWBPM REMAP_22BITS RANGE 0x8000 0xbfff 0x47
in>HWBPM REMAP_22BITS DISPLAY
HWBPM Remappings for 0x3CA:
Range0:    0x4000..0x7FFF mask: 0x3e
Range1:    0xC000..0xFFFF mask: 0x3f
Range2:    0x8000..0xBFFF mask: 0x47

Delete a remapping:
in>HWBPM REMAP_22BITS DELETE 1
in>HWBPM REMAP_22BITS DISPLAY
HWBPM Remappings for 0x3CA:
Range0:    0x4000..0x7FFF mask: 0x3e
Range1:    0x8000..0xBFFF mask: 0x47

Retrieve the default remapping for the currently set derivative:
in>HWBPM REMAP_22BITS MCUID_DEFAULT
in>HWBPM REMAP_22BITS DISPLAY
HWBPM Remappings for 0x3CA:
Range0:    0x4000..0x7FFF mask: 0x3e
Range1:    0xC000..0xFFFF mask: 0x3f
```

## Associated Environment Variables

The following sections describe the Hardware Breakpoint Settings environment variables which are used by the Target Interface. These variables are:

[HWBPD MCUIDnnn BKPT REMAPn](#)

[HWBPD MCUIDnnnn HBPMn](#)

These variables are stored in the [“targetName”] section from the project file.

Example of the [GDI] target section from a project file:

[GDI]

```
HWBPD_MCUID03C6_HWBPM0=HWBPM MODE AUTOMATIC BPM16BITS 0x28 SKIP_OFF
HWBPD_MCUID03C6_HWBPM1=HWBPM SET16BITS 0x0 0x0 0x0 0x0
HWBPD_MCUID03C6_HWBPM2=HWBPM SET22BITS 0x0 0x0 0x0 0x0
HWBPD_MCUID3C6_BKPT_REMAP0=HWBPM REMAP_22BITS RANGE 0x4000 0x7FFF 0x3E
HWBPD_MCUID3C6_BKPT_REMAP1=HWBPM REMAP_22BITS RANGE 0xC000 0xFFFF 0x3F
HWBPD_MCUID3C7_BKPT_REMAP0=HWBPM REMAP_22BITS RANGE 0x4000 0x7FFF 0x3E
HWBPD_MCUID3C7_BKPT_REMAP1=HWBPM REMAP_22BITS RANGE 0xC000 0xFFFF 0x3F
HWBPD_MCUID3CA_BKPT_REMAP0=HWBPM REMAP_22BITS RANGE 0x4000 0x7FFF 0x3E
HWBPD_MCUID3CA_BKPT_REMAP1=HWBPM REMAP_22BITS RANGE 0xC000 0xFFFF 0x3F
```

---

The Hardware Breakpoint Settings variables which are used by the Target Interface are described as shown in the following table.

| Topic             | Description  |
|-------------------|--|
| Short Description | Provides a short description of the variable.                      |
| Syntax            | Specifies the syntax of the variable in a EBNF format.             |
| Default           | Shows the default setting for the variable.                        |
| Description       | Provides a detailed description of the variable and how to use it. |
| Example           | Small example of how to use the variable.                          |

The following sections describe each variable available for the Target Interface. The variables are listed in alphabetical order.

---

## HWBPD\_MCUIDnnn\_BKPT\_REMAPn

### Short Description

Contains a [HWBPM](#) Command Line command to be used to set up the Hardware Breakpoint Remapping.

### Syntax

---

```
HWBPD_MCUIDnnnn_BKPT_REMAPn=<one HWBPM REMAP22BITS Command Line
command>
```

---

with `nnnn` specifying the current processor target mcuid. Therefore, note that `HWBPD_MCUIDnnn_BKPT_REMAPn` commands are clearly isolated for each current processor target/derivative mcuid, rather than being generic for the current target interface.

### **Default**

Defaults settings are retrieved according to the derivative from a common ini file.

### **Description**

The `HWBPD_MCUIDnnn_BKPT_REMAPn` variable specifies a command file definition using [HWBPM](#) REMAP22BITS Command Line command.

The variable name depends on the derivative MCU-ID and on the remapping range number.

Those variables are used to store the current Hardware Breakpoints Module remapping settings specified with the [HWBPM](#) REMAP22BITS Command Line command.

### **Example**

```
HWBPD_MCUID3C6_BKPT_REMAP0=  
    HWBPM REMAP_22BITS RANGE 0x4000 0x7FFF 0x3E
```

---

## **HWBPD\_MCUIDnnnn\_HBPMn**

### **Short Description**

Contains a [HWBPM](#) Command Line command to be used to set up the Hardware Breakpoint Settings support.

### **Syntax**

---

```
HWBPD_MCUIDnnnn_HBPMn=<one HWBPM Command Line command>
```

---

with `nnnn` specifying the current processor target mcuid. Therefore, note that `HWBPD_MCUIDnnnn_HBPMn` commands are clearly isolated for each current processor target/derivative mcuid, rather than being generic for the current target interface.

## **Default**

Defaults settings are retrieved according to the derivative from a common ini file.

## **Description**

The HWBPMn variable specifies the configuration of the Hardware Breakpoints module using [HWBPM](#) Command Line command. Three entries should be present in the project file.

Those variables are used to store the current Hardware Breakpoints Module settings specified either with the [HWBPM](#) Command Line command or through the [Hardware Breakpoint Configuration dialog](#).

## **Example**

```
HWBPD_MCUID03C6_HWBPM0=HWBPM MODE AUTOMATIC BPM22BITS 0x28  
SKIP_OFF  
HWBPD_MCUID03C6_HWBPM1=HWBPM SET16BITS 0x0 0x0 0x0 0x0  
HWBPD_MCUID03C6_HWBPM2=HWBPM SET22BITS 0x0 0x0 0x0 0x0
```



# Index

---

## Symbols

.abs 22

## Numerics

16-bits Break Module (User Mode) 69

22-bits Break Module (User Mode) 70

## B

Banked Memory Location dialog 43

Banked Memory Location Target commands 47

BREAKPOINT 26

Breakpoint 67, 68

    BREAKPOINT 26

    Message 26

Bus Trace 34, 38

## C

CMDFILE 60

CMDFILEn 62

Command Files 22, 55

Commands 47, 59, 71

COMSETTINGS 28

Connect 22

Connection 20

## D

Display Bank Memory Location dialog at  
    connection 47

DPAGE 45

DPAGE Banked Memory Area 45

## E

Environment variables 27

EPAGE 45

EPAGE Banked Memory Area 45

Erase Flash 34, 38

## F

Flash programming 57

## G

GDI

    Default target 27

    Menus 27

GDI > Command Files 22

GDI > Connect... 22

GDI > Load... 22

GDI > Reset 22

GDI > Set Bank... 23

GDI > Set Hardware BP... 23

gdi.tgt 27

## H

HALTED 25

Hardware Breakpoint 65

Hardware Breakpoint module

    Automatic (controlled by debugger mode) mode 67

    Disabled mode 67

    User controlled mode 68

Hardware Breakpoints SettingTarget commands 71

Hardware Connection 20

Highlights 6

HWBPM 72

HWBPM MODE 72

HWBPM REMAP\_22BITS 73

HWBPM REMAP\_22BITS DELETE 73

HWBPM REMAP\_22BITS DISPLAY 73

HWBPM REMAP\_22BITS MCUID\_DEFAULT 73

HWBPM REMAP\_22BITS RANGE 73

HWBPM SET16BITS 72

HWBPM SET22BITS 72

## I

inDART-HCS12 > About 38

inDART-HCS12 > Erase Flash 38

inDART-HCS12 > MCU Configuration 38

## L

Load Options 34

Load... 22

Loading an application 22

---

## M

MCU Communication 38  
Metrowerks Debugger  
    Status Bar 25  
Module base address 68  
Monitor Communication 34  
MONITOR-HCS12 > Communications... 34  
MONITOR-HCS12 > Erase Flash 34  
MONITOR-HCS12 > Load Options... 34

## N

Non Volatile Memory 57

## O

Overview 5

## P

Postload command file 57  
PPAGE 44  
PPAGE Banked Memory Area 44  
Preload command file 56  
PROJECT File 27  
PROJECT.INI 20  
PROTOCOL 29

## R

READY 25  
Requirements 6  
RESET 30  
Reset 22  
Reset command file 56  
RUNNING 25

## S

Set Bank... 23  
Set Hardware BP... 22  
Startup command file 56  
Status Message 25  
    HALTED 25  
    READY 25  
    Reset 25  
    RUNNING 25  
STEPPED 26  
STEPPED OVER 26

Stepping Message 26

    STEPPED 26

    STOPPED 26

    TRACED 26

STOPPED 26

## T

Target Command Files 55

Target commands 59

Target Interface Associated Command Files 55

Target Interface Command Files dialog 58

Target Interface Dialogs 43

    Target Interface Command Files dialog 58

TRACED 26

Trigger Module Settings 34, 38

## V

Variable 27

Various index tab 46

Vppoff command file 57

Vppon command file 57

## W

WATCHPOINT 26

Watchpoint

    WATCHPOINT 26